

## WARNING!

Rewiring of fluorescent fixtures for use with LED tubes should only be performed by individuals who have been properly trained to perform basic electrical maintenance and repair. Please review these instructions thoroughly before proceeding!


## General Safety Information

1. Review the diagrams thoroughly before beginning
2. Two people are recommended for installation, and performed by qualified personnel
3. All electrical connections must be in accordance with local codes, ordinance, and the National Electric Code. If you are unfamiliar with methods of installing electrical wiring, secure the services of a qualified licensed electrician.
4. Before starting the installation, disconnect the power by turning off the circuit breaker or by removing the appropriate fuse at the fuse box. Turning the power off using the light switch is not sufficient to prevent electrical shock.
5. Equipment should be mounted in locations and at heights where it will not readily be subject to tampering by unauthorized personnel.

### Step 1: Remove the original fluorescent tube



### Step 5: Connect driver's input line and kit's line



### Step 2: Remove the ballast



### Step 6: Fasten the magnetic strip and driver



### Step 3: Remove other irrelevant parts of the troffer



### Step 7: Close the cover of the driver



### Step 4: Connect the driver's output line and power line



### Step 8: Close the cover of the troffer

